PHILIPS

Fabric Shaver

Removes fabric pills Suitable for all garments 2 Philips AA batteries incl.







Fabric Shaver

Revive your old garments instantly

The Philips fabric shaver allows you to easily and quickly remove fabric pills from all types of garments. All your garments, from jumpers to blankets, will look like new again!

Effective and quick pill removal

- Large blade surface for covering a large area at once
- Up to 8800 rounds/min blade rotation for effective removal
- Height adjustment cap for the most delicate garments
- 3 mesh hole sizes to tackle all sizes of pills

Easy to use

- The pill container is easy to remove and empty
- The cleaning brush helps to clean your appliance after use
- 2 Philips AA batteries are included in the package

Fabric Shaver

Highlights

Large blade surface



Large blade surface ensures that larger area of the garment is covered at the same time, hence less strokes are needed to make your garment look new again

Specially designed shaving head

Due to the three different hole sizes, all sizes of fabric pills will be drawn into it and effectively removed from the fabric.

8800 rounds/min blade rotation



Blades rotate up to 8800 rounds/min for effective and quick removal of the fabric pills from your garments

Large removable pill container



The container, where the shaved off pills are stored, is easy to remove and empty.

© 2019 Koninklijke Philips N.V. All Rights reserved.

their respective owners.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or

lssue date 2019-05-01 Version: 8.1.1

EAN: 08 71010 36582 83

www.philips.com



GC026/00

Specifications

Accessories Brush Delicate fabric protector

Sustainability User manual: 100% recycled paper

Technical specifications Power type: 2 AA batteries

Weight and dimensions

Product dimensions (W x H x D): 12.3 x 5.8 x 8 cm



Height adjustment cap

garments

Cleaning brush

the appliance.

The height adjustment cap enables you to

remove fabric pills even from the most delicate

The cleaning brush helps to easily clean your

start guide included in the packaging to clean

appliance after use. Please follow the quick

2 Philips AA batteries are included in the package.