

# BRAUN

## PurEase Toaster

### HT3010

[www.braunhousehold.com](http://www.braunhousehold.com)

## Product highlights



### Comfort lift

With the comfort lift the bread can be moved up to a higher position and is kept there for safely retrieving



### Easy access and control

Reheat, stop and defrost functions are located at the top of the toaster. Lift and browning setting control are on side.



### Removable crumb tray

All crumbs are collected in the tray and can easily be disposed.



### Variable browning

With the 7 different settings you can choose your preferred degree of browning, no matter what type of bread.



### Removable warming rack

Warm or toast certain breads and pastries with this removable attachment.



### PurEase Breakfast collection

Perfectly designed Breakfast collection for your easy start in the morning.

## Technical data

Model	HT 3010 WH HT 3010 BK
Colours	White/black
SKU white	0X23010008
SKU black	0X23010009
EAN white	8021098760012
EAN black	8021098760029
Slot type	2-slot
Slot size	12,5x13x3,5 cm
Warming rack (removable)	●
Variable browning control	●
Comfort lift (blocking)	●
Removable crumb tray	●
Cable storage	●
Centring system	●
Cancel function	●
Reheat function	●
Defrost function	●
Auto shut-off	●
Wattage	1000 W
Product dimensions (WxDxH)	25 x15x24 cm
Product weight	ca. 1500 g
Gift box dimensions (WxDxH)	28,3x18,6x28,5 cm
Gift box weight	ca. 2130

Braun's most compact toaster fits every kitchen counter.