

PHILIPS

Water filter cartridge

Same as CA6702/00

Prolong machine lifetime

Protects against limescale

CA6702/10



The best water for a more tasteful coffee

Freshly filtered water ensures intense aroma

The innovative BRITA INTENZA+ water filter cartridge has been specially developed to protect your valuable Philips Saeco espresso machine against limescale. It filters the water, intensifying the aroma and pure taste of your coffee.

Intensive coffee aroma

- Adjustable water filter settings
- Freshly filtered water for a richer coffee aroma

Reliable machine protection

- More efficient brewing process
- Protects your system against lime-scale build-up
- Only use Philips consumables

Prolong lifetime

- Cleaner water prolongs the life of your espresso machine

Ready to use

- Click & go system
- Replace every 2 months


Highlights

Adjustable water filter



The water filter settings can be adjusted to the hardness of your water. Simply turn the adjustment ring on the Intenza+ water filter. Set it to A for soft water areas, B for medium water hardness (factory setting) or C for hard water. This will ensure optimal limescale protection and best taste.

Freshly filtered water




Water is a crucial ingredient of every espresso – so for optimum taste, it's always best to filter it professionally. That's why all Saeco espresso machines can be optionally fitted with the innovative INTENZA+ water filter, which we co-developed with BRITA, the world's No. 1 in household water filters. Just set it to your location's hardness level, and its sophisticated technology does the rest. The result? Ideal water conditions for espresso with the most intense aroma.

Efficient brewing process



The water filter ensures a constant brewing temperature and consistent pressure during the brewing process, enhancing your espresso machine's performance.

Protects your system




The INTENZA+ water filter helps protect your machine against the build-up of limescale from tap water, which affects the taste and aroma of your coffee.

Cleaner water for your machine




The water filter extends the lifespan of your espresso machine, ensuring you can enjoy the best-tasting coffee for longer.

Click & go system



The water filter cartridge easily clicks into the water tank and is ready to use in less than 30 seconds.

Replace every 2 months



A regular change of the cartridge is important for optimum coffee taste and for consistent protection of your coffee machine. Please replace the cartridge every two months.

Philips Original



Only use Philips consumables to make sure your machine runs smoothly for longer. Philips consumables are the only recommended consumables for Philips and Saeco machines.

Specifications

Technical specifications

Includes: 1 water filter cartridge

Weight and dimensions

Dimensions of product (WxDxH): 40 x 70 x 60 mm

Weight of product: 0.118 kg

