

# PHILIPS

## Sneaker Cleaner

3x brushhead

Blue/Yellow

4x AA battery



GCA1000/60



## The easy way to keep your sneakers clean

Including three brushes for different material

The Philips Sneaker Cleaner is designed to make cleaning your sneakers easy and effective. Select the right brush for your sneaker, wet the brush with some water and soap, apply it to your sneakers and they will look fresh in no time.

### Effective cleaning

- The rotating brush cleans effectively

### Easy cleaning

- Simple to use in three steps

### Safe for your sneakers

- Three brushes to clean different material
- Sponge brush for delicate surfaces
- Soft brush for multipurpose use
- Hard brush for tough surfaces

### Take it on the go

- Clean sneakers wherever you go
- Including 4x AA batteries



# Highlights

## Effective cleaning




With up to 500 rotations per minute the Philips Sneaker Cleaner delivers an effective clean.

## Take it with you



You can take the battery powered sneaker cleaner with you on the go, so you can enjoy clean sneakers no matter where you are.

## Hard brush



The hard brush is great to use for tough materials like textured rubber or the rubber sole of your sneaker.

## Simple to use



Simply wet the brush with water and soap, switch on the Philips Sneaker Cleaner and wipe the sneaker with a clean towel when done.

## Sponge brush



The sponge brush is ideal to use for delicate materials like PVC, leather, suede and smooth rubber.

## Battery powered




The Philips Sneaker Cleaner comes with 4x AA batteries included so you can start cleaning your sneakers right away .

## Three brush heads



Select the sponge, soft or hard brush to safely clean the material your sneaker is made of.

## Soft brush



The soft brush is designed to use on multiple surfaces and ideal for mesh and canvas.

# Specifications

**Technology**

Rotations per minute: 500 RPM

Waterproofness: IPX5

**Battery**

Battery type: 4x AA battery

Power: 6 V

Battery run time: 80 minutes at 450g load

**Safe for your sneakers**

3 Brushes included: Sponge, Soft Brush, Hard Brush

**Guarantee**

2 year worldwide guarantee: Upon registration

**Dimensions**

Packaging dimensions (WxHxL): 116 mm x 204 mm x 93 mm

Product dimensions (WxHxL): 60 mm x 69 mm x 170 mm

**Weight**

Product weight incl batteries: 0.351 kg

Total weight with packaging: 0.501 kg kg

**Recyclable**

Product packaging: 100% recycable

User manual: 100% recycled paper

